

Stalker Walker Bow Sling

Model SWBS-170



The **Stalker Walker Bow Sling** is made to hold a compound bow, gun, or even to carry a turkey out of the woods. The sling holds your bow tightly beside you while offering easy access in and out of the sling. By loosening the cord locks, taking the front loop off the bow cam and limb, tilting bow down and pulling away from you. The sling remains on your body while shooting. The sling offers a non-slip rubber shoulder pad which helps the sling to stay in place. May be used left or right handed by switching the torso strap 1/2 turn "See Directions".

- For transporting your bow to and from the field
- Silent and EZ bow removal
- Make your hands (FREE) to glaze through binoculars, climb tree stands, or just to relax
- Use left or right handed
- Use during Archery Hunting, Archery Tournaments, or just Target Shooting

Stalker Walker Bow Sling

Directions:

For Right-Handed Archery Shooters

- 1.) Slip wide strap (Shoulder Strap) over left shoulder while keeping narrow strap (Torso Strap) under right arm.
- 2.) Insert bottom cam and limb of bow into rear sling loop, and then insert top cam and limb of bow into front sling loop. Proper adjustment is achieved when cord lock touches bowstring.

To adjust Shoulder Strap

- 1.) Locate adjustment buckle (located on wide strap in front) to raise bow slide buckle towards shoulder. To lower bow, slide buckle towards bow cam.

To adjust Torso Strap

- 1.) To lengthen torso strap, slide buckle (B) towards the buckle (A).
- 2.) To shorten torso strap, slide buckle (B) away from buckle (A).

For Left-Handed Archery Shooters

- 1.) The torso strap must be reversed making sure wide strap with adjustment buckle is in front. Buckle (A&B) on torso strap must be in front as well.
- 2.) Insert bottom cam and limb of bow into rear sling loop, and then insert top cam and limb of bow into front sling loop. Proper adjustment is achieved when cord lock touches bowstring.

To reverse Torso Strap

- 1.) Loosen buckle (A) to allow torso strap to slide off the shoulder strap. Repeat with buckle (C).
- 2.) Rotate torso strap ½ turn making sure buckle (A&B) are in front. Insert shoulder strap through torso strap loop adjust buckle (A).
- 3.) Repeat steps 2 using buckle (C).

Gadget Grabbers Outdoors LLC.™

14740 Oak Grove Dr. Unit 129

Doylestown, Ohio 44230

Office: 1-330-658-3897

Toll Free 1-877-544-2468

www.gadgetgrabbersoutdoors.com



